

*The frequency stability defaults to the lowest available programming option in house. This will be noted on the individual part number product page.

*Call Digi-Key and a Sales Representative will enter your desired frequency. For online orders, you may enter it into the web notes.

Programmable parts are non-cancelable and non-returnable