

# Jupiter SE880 Product Description

80417ST10119a r2 – 2014-06-10











- 5.2.5. Push to Fix Mode (PTF) ..... 20
- 5.3. Differential Aiding ..... 21
  - 5.3.1. Satellite Based Augmentation Systems (SBAS) ..... 21
- 5.4. Time Mark Pulse (1PPS) ..... 21
- 5.5. Interfaces ..... 22
  - 5.5.1. Main Serial Interface configuration ..... 22
  - 5.5.2. NMEA Output Messages ..... 23
  - 5.5.3. SiRF OSP Output Messages ..... 23
  - 5.5.4. Auxiliary Serial Interface ..... 24
  - 5.5.5. External Antenna Connection ..... 24
- 5.6. Functions and Capabilities ..... 24
- 5.7. Jupiter SE 880 Pin out..... 26
  - 5.7.1. Pinout Description ..... 26
- 6. Mounting SE880 on your board ..... 29**
  - 6.1. General..... 29
  - 6.2. Packing System..... 29
- 7. Conformity Assessment ..... 30**
  - 7.1. EC Declaration of Conformity ..... 30
- 8. SE880 EVK: Evaluation Kit..... 31**
- 9. SE880 RDK: Reference Design Kit ..... 32**
- 10. Safety Recommendations..... 33**
- 11. Document History ..... 34**





## 1.4. Document Organization

This document contains the following chapters :

[Chapter 1: “Introduction”](#) provides a scope for this document, target audience, contact and support information, and text conventions.

[Chapter 2: “Overview”](#) gives an overview of the features of the product.

[Chapter 3: “General Product description”](#) describes in details the characteristics of the product.

[Chapter 4: “Environmental requirements”](#) deals about environmental spec.

[Chapter 5: “SE880 Characteristics”](#) gives an overview of the product’s characteristics including power supply, communication ports and pinout.

[Chapter 6: “Mounting on your board”](#) describes how to handle the device and its packaging system.

[Chapter 7: “Conformity Assessment”](#) provides overview about product assessments.

[Chapter 8: “Evaluation Kit”](#) provides a scope an overview about the SE880 Evaluation kit.

[Chapter 9: “Reference Design Kit”](#) provides a scope an overview about the SE880 Reference kit

[Chapter 10: “Conformity Assessment Issues”](#) provides some fundamental hints about the conformity assessment that the final application might need.

[Chapter 11: “Safety Recommendation”](#) provides some safety recommendations that must be follow by the customer in the design of the application that makes use of the AA99-XXX.

## 1.5. Text Conventions



**Danger – This information MUST be followed or catastrophic equipment failure or bodily injury may occur.**



**Caution or Warning – Alerts the user to important points about integrating the module, if these points are not followed, the module and end user equipment may fail or malfunction.**



**Tip or Information – Provides advice and suggestions that may be useful when integrating the module.**

All dates are in ISO 8601 format, i.e. YYYY-MM-DD.

## 1.6. Related Documents

- Jupiter SE880 Hardware User Guide
- Jupiter SE880 EVK User Guide



- Jupiter SE880 Ref Design User Guide









## 2.2. SE880 SiP 3D Technology

The Jupiter SE880 is a 3D SiP (System in Package) device. the 3D technology allows to embed active and passive components into the PCB.

SiP means the integration of several integrated circuits and components of various technologies in a single package, resulting in one or several electronic systems.



SiP Concept



3D PCB package

3D SiP key benefits are :

- Miniaturization
- Functional performance improvement
- Combination of several functions
- Excellent electrical by low inductances
- Excellent thermal performance (top and back side heat transfer)
- Embedded EMI shield
- Cost reduction
- Speed-to-market due to the reuse of existing ICs
- Complete system integration





## 2.5. Jupiter SE880 minimal external BOM


The Jupiter SE880 requires two external reference clocks:

- 16.369MHz TCXO
- 32.768kHz (XTal)

antenna and a 1.8V always ON supply.

Supply can be a 1.8V supply that is backed up by a very low current 1.8V LDO that will supply the 20uA typical when the GPS has been shut down into Hibernate mode.

An EEPROM / SPI Flash memory can be added in order to store CGEE and/or SW patches.







### 3.2.2. DC Electrical Characteristics

Symbol	Parameter	Min	Typ	Max	Unit
VDD	Supply voltage input		1.8		V
IDD (peak)	Supply current, peak acq.		47	90	mA
IDD (ave)	Supply current average, tracking, LDO mode		37		mA
IDD (ave)	Supply current average, tracking, Switcher mode		30		mA
IDD (Hib)	Supply current, hibernate state		20		μA
VOL	Low level output voltage, IOL 2mA			0.4	V
VOH	High level output voltage, IOH 2mA	0.75*V <sub>DD</sub>			V
VIL	Low level input voltage	-0.3		0.45	V
VIH	High level input voltage, IOH 2mA	0.7*V <sub>DD</sub>		3.6	V
RPU	Internal pull-up resistor equivalent	50	86	157	kΩ
RPD	Internal pull-down resistor equivalent	51	91	180	kΩ
LI	Input leakage at VI=1.8V or 0V	-10		10	μA
LO	Tristate output leakage at VO=1.8V or 0V	-10		10	μA
CI	Input capacitance, digital output		8		pF





## 5. SE880 Characteristics

### 5.1. Power Supply

The SE880 requires only one VDD supply voltage of 1.8 volts. Rather than having a “split” power supply design of main and backup, the SE880 manages all of its power modes internally and VDD supply intended to be kept alive all the time.

First power up may take 300ms (typical) due to internal RTC startup time after which the SE880 will enter into the lowest power “hibernate” state.

Upon pulsing the ON\_OFF signal, the SE880 will transition to the “operate” state.

Pulsing the ON-OFF signal a second time will transition the Se880 back into the “hibernate” state.




---

Power supply voltage, noise and ripple must be between 1.75V and 1.85V for all frequencies up to 3MHz. Above 3MHz, the noise and ripple component must not exceed  $\pm 15\text{mV}$ . To help meet these requirements, a separate LDO for the Se880 is suggested.

---

See HW User Guide for details.

#### 5.1.1. Pseudo Battery Back-up

In SE880, removal of the 1.8 volt supply results in losing RTC time and SRAM data. The main supply voltage can be switched to a backup supply external to the SE880 provided the receiver is allowed time to enter the hibernate state.

See HW User Guide for details.

### 5.2. Power Management

After power up the SE880 boots from the internal ROM to Hibernate state. The operation of requires ON\_OFF interrupt to wake up for Normal (Navigation, Full on) mode.

Modes of operation:

- Full on (Navigation, Full Power)
- Power management system modes
- Hibernate state

Full on mode.

SE880 boots for internal 1.2V LDO regulator mode. Internal Switcher mode regulator reduces power consumption and requires a binary command from host to enable Switcher mode.





quality navigation solution. The also wakes up when requested by a signal on the ON-OFF line.

## 5.3. Differential Aiding

### 5.3.1. Satellite Based Augmentation Systems (SBAS)

The SE880 is capable of receiving WAAS and EGNOS, MSAS, GAGAN differential corrections which are regional implementations of SBAS. SBAS improves horizontal position accuracy by correcting GPS signal errors caused by ionospheric disturbances, timing and satellite orbit errors.

## 5.4. Time Mark Pulse (1PPS)

A 1PPS time mark pulse is provided as an output with a width of 200ms. This signal has not been verified or characterized for all operational conditions.



## 5.5. Interfaces

### 5.5.1. Main Serial Interface configuration

User can select the serial interface (host port) between UART, SPI (slave) or I<sup>2</sup>C (master/slave) during power up boot depending upon how the CTS\_SPI and RTS\_SPI pins are strapped at power up. Either leave the pin floating, apply a 10K resistor to +1.8V (PU) or apply a 100K resistor to GND (PD).

Mode	CTS_SPI (internal pull-down)	RTS_SPI (internal pull-up)
UART	PU	Leave floating
I2C	Leave floating	PD
SPI	Leave floating	Leave floating

#### 5.5.1.1. Baud Rate Detection

GPIO0 and GPIO1 can be used to configure the serial interface to output NMEA at standard baud rates. If is not using I<sup>2</sup>C or SPI flash devices on GPIO0 and GPIO1. Table 4 lists the settings for GPIO0 and GPIO1 to configure the baud rate at start-up.

Table 5 GPIO Pull Directions for Configuring NMEA Output Rates at Start-up

GPIO0	GPIO1	Protocol	Baud Rate
Pull high	Pull high	NMEA	4800
Pull high	Pull low	NMEA	9600
Pull low	Pull high	NMEA	38400
Pull low	Pull low	OSP	115200



Note: The default data format for UART: 8 data bits, no parity, 1 stop bit

After start-up, the GPIOs can be released for other purposes.





**Note:**

This flexibility is not available if any MEMS or non-volatile memory devices are attached to the auxiliary serial bus. The internal software default baud rate is NMEA 4800 when an EEPROM or SPI flash device is attached, but can be changed via a CCK patch or an OSP message.

Failure to tie GPIO0 and GPIO1 high or low in the absence of both SPI flash and EEPROM causes an increase in standby and hibernate current and also causes the start-up configuration of the UART to be indeterminate.

### 5.5.2. NMEA Output Messages

NMEA v3.0 is the default protocol. The following messages are output by default:

- RMC = 1 second update
- GGA = 1 second update
- GSA = 1 second update
- GSV = 5 second update

Reference the NMEA protocol manual for additional message details.

### 5.5.3. SiRF OSP Output Messages

SiRF One Socket Protocol (OSP) is supported. This is an extension of the existing SiRF Binary protocol.

The following messages are output once per second:

- MID2
- MID4
- MID9
- MID41
- MID56, 5
- MID56, 35

Reference the SiRF One Socket Protocol manual for additional message details.



### 5.5.4. Auxiliary Serial Interface

The provides an auxiliary serial interface that can be configured as either a master I<sup>2</sup>C interface or a master SPI bus. Only one of these buses may be implemented on a receiver.

At start-up, the receiver automatically detects either an I<sup>2</sup>C EEPROM or a SPI serial flash memory and sets itself appropriately. If does not detect memory of either type, the system is configured for an I<sup>2</sup>C bus for sensor interface.

### 5.5.5. External Antenna Connection

The RF connection for the external antenna has a characteristic impedance of 50 ohms.

SE880 with its ultra sensitive RF frontend allows direct connection with passive antennas.

Jupiter SE880 has internal double stage LNA. LNA setting msut be done accordingly with the connected antenna and depending on the antenna gain in active antenna is used.

See SE880 HW User Guide for details.

## 5.6. Functions and Capabilities

Feature	Description	Availability
<b>SBAS (WAAS, EGNOS, QZSS)</b>	Improve position accuracy by using freely available satellite based correction services called SBAS (Satellite Based Augmentation System).	Yes
<b>Low Signal Acquisition</b>	Acquires satellites and continues tracking in extremely low signal environments.	Yes
<b>Low Signal Navigation</b>	Continues navigating in extremely low signal environments.	Yes
<b>Time Mark Pulse (1PPS)</b>	A timing pulse generated every second the receiver is in a valid navigation state (5 SVs required for initial pulse start-up).	Yes
<b>MEMS</b>	3-axis accelerometer support for static detection and wake-up. 3-axis magnetometer support for compass heading.	A
<b>3 Day CGEE</b>	AGPS using prediction of ephemeris from live (downloaded from satellites), ephemeris stored in memory.	Yes
<b>14 Day SGEE</b>	AGPS using server-generated extended ephemeris is now compatible with 14-day prediction files available from the server. These files can be saved EEPROM or host memory.	A



<b>Adaptive Jammer Detection</b>	System scan for up to 8 CW jammers for removal by the GPS.	Yes
<b>2.4GHz Notch Filter</b>	System can reject 2.4GHz signals at the antenna port input up to 50dB attenuation.	Yes
<b>Fast Time-Sync</b>	Determine time quickly from the GPS satellites and then stop receiving satellites.	A
<b>Almanac Based Positioning</b>	Allows fast cold starts TTFF 22 s. typ. based on factory set (or broadcast or pushed) Almanac data.	A
<b>SPI Flash Support</b>	Supports 2 and 4 Mb SST and EON SPI flash devices. uses flash memory for storage of almanac, EE, data logging, crystal and XO temperature models and patch code.	A
<b>Data Logging</b>	The embedded data logging function is configurable and will save data on either parallel or SPI flash.	A
<b>GPIO Baud Rate and Protocol Detection</b>	Baud rate and protocol selection can be set upon start up through GPIO0 and GPIO1 configuration.	Yes
Yes = always enabled                      A = available, but not enabled by default		





8	VKA	PWR	1.8v keep alive input for I/O and internal blocks
9	VDD	PWR	Main supply voltage, 1.8V (ALWAYS ON)
10	GPIO8	I/O	General Purpose Input/Output
11	GPIO3	I/O	General Purpose Input/Output
12	RTC_XI	CLK	RTC crystal or CMOS RTC clock input
13	RTC_XO	CLK	RTC crystal or open if no crystal
14	GPIO4	I/O	General Purpose Input/Output
15	GPIO2	I/O	General Purpose Input/Output
16	GPIO1	I/O	<ul style="list-style-type: none"> <li>• Baud Rate and Protocol Detection</li> <li>• General Purpose Input/Output</li> </ul>
17	GPIO0	I/O	<ul style="list-style-type: none"> <li>• Baud Rate and Protocol Detection</li> <li>• General Purpose Input/Output</li> </ul>
18	GND3	PWR	GROUND
19	VCC_TCXO	PWR	TCXO voltage supply
20	GND4	PWR	GROUND
21	TCXO_CLK	CLK	RF reference clock input; TCXO input or bare crystal output connection for built-in XO option
22	XTAL_CLK	CLK	Bare crystal input connection for built-in XO option or open for TCXO
23	GND5	PWR	GROUND
24	GND6	PWR	GROUND
25	GND7	PWR	GROUND
26	GND8	PWR	GROUND
27	RF_IN	I	GPS RF Input (3V DC max rating)
28	GND9	PWR	GROUND





## 6. Mounting SE880 on your board

### 6.1. General


Telit SE880 module has been designed in order to be compliant with a standard lead-free SMT process. For detailed information about PCB pad design and conditions in SMT process please refer to “SE880 HW User guide”.

### 6.2. Packing System

According to SMT process for pick & place movement requirements, Telit SE880 modules are packaged in Tape&Reel.

Two different T&R are available:

- Hi-Capacity T&R : 4000 pcs each.
- Low-Capacity T&R: 500 pcs each



## 7. Conformity Assessment


### 7.1. EC Declaration of Conformity



## EC DECLARATION OF CONFORMITY



1. **SE880** (product name)
2. Telit Communications S.p.A - loc. Sa Illetta, S.S. 195, Km 2.300, 09122 Cagliari - ITALY (manufacturer)
3. This declaration of conformity is issued under the sole responsibility of the manufacturer
4. GPS Receiving Module





5. The object of the declaration described above is in conformity with the relevant Community harmonisation:  
European Directive 1999/05/EC (R&TTE)
6. The conformity with the essential requirements of the 1999/05/EC has been demonstrated against the following harmonized standards:

EN 60950-1:2006 + CORR:2006 + A11:2009 + A1:2010 + A12:2011 + AC:2011	For article 3.1 (a): Health and Safety of the User
EN 301 489-1 V1.9.2 EN 301 489-3 V1.4.1	For article 3.1 (b): Electromagnetic Compatibility
EN 300 440-1 V1.6.1 EN 300 440-2 V1.4.1	For article 3.2: Effective use of spectrum allocated
7. The conformity assessment procedure referred to in Article 10 and detailed in Annex V of Directive 1999/05/EC has been followed with the involvement of the following Notified Body:  
CETECOM ICT Services GmbH Untertürkheimer Straße 6-10, D-66117 Saarbrücken, Germany.  
Notified Body Number: 0682  
Due to the equipment dimensions, the CE marking cannot be visibly and legibly affixed on the product itself.  
Thus, **CE 0682** is affixed to the packaging, if it exists, and to the accompanying documents.
8. The Technical Construction File (TCF) relevant to the product described above, and which supports this Declaration of Conformity, is held at: Telit Communications S.p.A Via Stazione di Prosecco, 5/b 34010 Sgonico (TRIESTE) ITALY

Signed for and on behalf of Telit Communications S.p.A

Trieste, **2013-04-09**

  
 EMEA Quality Director  
 Guido Walcher


  
 Quality Manager  
 Cesare Robelli

Technical Construction File : 30417TCF0035a Rev.0



## 8. SE880 EVK: Evaluation Kit

The SE880 Evaluation Kit is available to assist in the evaluation and integration of the module in custom applications. The Development Kit contains all of the necessary hardware and software to carry out a thorough evaluation of the module.



## 9. SE880 RDK: Reference Design Kit

While the SE880 EVK is intended to provide customer with the lab evaluation, so EVK needs to be connected to a PC, the SE880 Reference Design Kit is intended to provide customer with a tool to evaluate the SE880's performances when the Jupiter is mounted following Telit's Reference Design recommendations and using passive antennas.

SE880 Reference Design Kit is a plastic box containing SE880 mounter in a reference board with four passive antennas.

The box is a portable compact tool, manily intended for drive tests, allowing customer to switch among to 4 diffent patch passive antennas in order to test and understand device performances and customer needs.

See SE880 Reference Design Kit User Guide for details (TBC).





